

Your dwelling is fitted with an Aereco Mechanical Extract Ventilation system.



BXC

## Maintenance instructions for your extract units




Kitchen

Bath-  
room

WC


once a year

1




Remove the cover.

2




Grab the shutter box with two fingers and pull.

3




Clean the cover and the shutter box with warm water and detergent or put in the upper compartment of the dishwasher.

4



Return the clean (slightly tilted) shutter box to the unit housing.

5



Put the cover back into place.